ASSEMBLY INSTRUCTIONS

MODELS: PLTSBUDMDUALSI + PLTSDTMSI + PLTSBUDMSGLSI-AI



Before assembly, please remove all parts from the carton, verifying that you have the correct quantities, and read all the instructions.

IN THE CARTON:





M6 × 20





M6 × 28





INSTRUCTIONS:

RUCTIONS:	
For Acrylic Panels (PLTAP) use the shorter bolt (M6 x 20) and discard longer bolt.	For Acrylic Panels (PLTAP) use the shorter bolt (M6 x 28) and discard longer bolt.
Acrylic Panel (PLTAP)	Fabric Panel (PLTFP)
PLTSBUDMDUALSI 5mm M6 × 20	15mm M6 × 28
PLTSDTMSI 5mm M6 × 20	15mm M6 × 28
PLTSBUDMSGLSI 5mm M6 × 20	15mm M6 × 28